

grey/white to immobiliser & VAG 1551, yellow/black & green/black to gauges, blue/white to speed sensor

Black to JX fuel solenoid lead

6 pin connector to loom to dash for gauges, immobiliser, etc.

Red/black & brown to fuel pump

White, brown, red/white & yellow to T4 for lambda probe

Red/green to starter solenoid

T28a connector & 2xT3 connectors to engine

Relays

green/red, brown & black to Coil

Green/yellow & brown to charcoal filter solenoid

white/yellow & brown/blue to air temperature sensor

red/green & black/yellow to Air Mass Meter

JX wiring retained for:
Water temp gauge sender
Water pump run-on switch
Oil pressure switches (low & high pressure)

T68 connector

ECU

See detail diagrams for relays and JX connections

Wiring Loom for Golf AGG Engine in place of JX in Transporter T3

Gary Dawson
2010-08-06

